CABINET PARTS

For Model: 3XARG497WP01
(White)



2	2174748	Front Roller (2)
3	489456	Screw
4	981122	Roller (Rear) (2)
5	489427	Screw
6	2155013	Clip, Grille
7	489478	Screw
9	2181911	Shim
10	2158579	Encloser, Terminal Block
11	1129346	Terminal Block
12	1129449	Bushing
13	2171868	Shim, Hinge Top
14	489284	Screw
15	1129262	Hinge Cover
16	2171851	Hinge Bottom (R.H)
17	489211	Screw
18	489399	Screw
21	1110708	Filler, Wrapper
22	2155477	Grille
23	489483	Screw
24	2165297	Wiring Assembly
25	2167227	Gasket
26	489463	Screw
27	2171865	Hinge, Top (2)
40	1129332	Service Cord
41	940139	Drain Fitting
42	1108438	Extension Tube
43	1108439	Clip, Drain Tube
47	2189567	Cover, Unit
48		Cabinet (Not A Serviceable Part)
49	1119787	Hinge Cover
52	489348	Clamp
53	489084	Screw
54	2155311	Door Closer, Lower Cam (2)
55	489420	Screw

REFRIGERATOR LINER PARTS

For Model: 3XARG497WP01
(White)



1		Liner (Not A Serviceable Part)
2	2194744	Escutcheon, Meat Pan Control
3	2182757	Slide Meat Pan Control
4	2169193	Shroud, Light
5	2171846	Release Valve
6	2182147	Louver
8	1110718	Stud, Rear (6)
9	2181796	Shelf Ladder
10	487539	Screw
11	486298	Screw (2)
12	2179374	Wine Rack
13	1123919	Bracket Retainer
14	489290	Screw
15	2175155	Air Diffuser Assembly
16	2161470	Air Diffuser Cover
17	2150331	Cover, Conduit
18	2162085	Socket
19	2155290	Reservoir
20	851682	Light Bulb
21	2174436	Light Lens
22	488280	Screw (2)

REFRIGERATOR SHELF PARTS

For Model: 3XARG497WP01

(White)



1	2174041	Shelf Assembly, Glass Sliding (2)
2	2189531	Snack Bin
3	2189616	Cover, Crisper
4	2174442	Gasket, Cover (Front)
6	2179259	Glass, Meat Cover
8	2189601	Cover, Meat Pan
9	2174042	Frame, Shelf (2)
10	2189529	Crisper Pan
11	2179343	Front, Crisper Pan
12	2179342	Slide, Humidity Control
13	2189533	Trim, Handle
14	2189530	Meat Pan
15	2169933	Egg Bin
16	2164373	Egg Carrier
17	2169935	Cover
18	2179350	Deflector
19	2189532	Trim, Handle
20	2172943	Shelf Stud
21	1110718	Shelf Stud
22	2174045	Shelf, Snack Bin
23	2174468	Shelf, Slide (Side To Side)
24	2189620	Trim, Handle
25	2169608	Hook, Shelf
26	489419	Screw
27	2174422	Track, Shelf

FREEZER LINER PARTS

For Model: 3XARG497WP01

(White)



1		Liner (Not A Seviceable Part)
2	1115380	Slide, Ice Door
3	2171712	Door, Ice Compartment
5	489478	Screw
6	842534	Clip, Air Duct (2)
7	1115317	Support, Stud (4)
8	2174249	Shelf
9	2195902	Trim, Basket
10	2181761	Basket, Tall
11	2181762	Basket, Slope
13	2176134	Grommet (4)
14	2155572	Wiring Cover
15	489355	Screw
17		Shelf Track
	2181760	Right Side (2)
	2181759	Left Side (2)
18	487042	Screw
19	1115373	Switch, Rocker Arm
20	946355	Stud
21	946356	Stud, R.S.Front
22	1106982	Stud, L.S. Rear
28		Slide, Ice Container
	1119237	Left Side
	1119293	Right Side
29	489100	Screw

AIR FLOW PARTS

For Model: 3XARG497WP01
(White)



1	2182119	Fan Scroll
2	2155590	Retainer, Fan Motor
3	2161231	Air Scoop
5	2176071	Air Duct Freezer
6	2149544	Diffuser Air Duct
7	2154976	Fan Motor
8	2169142	Fan Blade
10	2176759	Fan Grommet (2)
11	2182146	Duct, Icemaker
12	2189564	Harness, Fan Evaporator, And Heater, Bi-Metal
13	2155788	Gasket Cover
14	2172840	Wire Tie
16	2155783	Gasket
17	2155611	Cover, Evaporator
18	489355	Screw
21	489478	Screw
22	2161484	Support, R.S
23	2155766	Support, L.S

MOTOR AND ICE CONTAINER PARTS

For Model: 3XARG497WP01

(White)



1	2183728	Bracket, Motor
2	2165167	Motor, Dispenser
3	2165210	Soleniod Assembly
4	2149100	Guide, Solenoid
5	2169193	Shroud, Light
7	2169490	Wiring Assembly, Ice Dispenser
8	489399	Screw
9	983663	Coupling, Motor
10	489478	Screw
11	2162085	Socket, Light
14	2182092	Ice Container
15	983668	Coupling, Conveyor
16	1118480	Stop, Cone
17	1119074	Feeder Cone
18	1119005	Spacer, Step (3)
19	1119007	Spacer, Flat (2)
20	1119006	Blade, Rotary
21	1119012	Blade, Rotary
22	1119013	Blade, Rotary
23	489235	Washer, Plain
24	1119009	Blade, Fixed (2)
25	2157405	Block, Blade
26	489229	Roll Pin
27	2181956	Conveyor
28	2171681	Drum
29	1118470	Drive Bar
30	2171682	Floating Baffle
31	1119018	Nut, Bearing
32	2155231	Control Arm
33	1119020	Spring, Return
34	1119021	Retainer Clip, Rod
35	488886	Screw
36	1129563	Shield, Wiring
37	2180348	Housing, Crusher
38	1119017	Deflector, Ice
39	489234	Washer, Plain
40	489236	Retainer Ring
41	2152021	Sleeve
44	2171709	Front Cover, Ice Container
45	851682	Light Bulb
46	2171706	Light Lens, Dispenser

REFRIGERATOR DOOR PARTS

For Model: 3XARG497WP01

(White)



1	2194275W	Refrigerator Door (Includes Item #8)
2	2173643	Retainer, Bottle
3	2177105	Door, Compartment
4	2156022	Trivet, Shelf
5	489463	Screw
6	2179607	Shelf Bin (3)
7	2194766W	Extension, Bottom
8	2159073	Door Gasket, Magnetic (Service)
9	2194759W	Handle
10	3400012	Screw
11	2179399	Shim
12	2195496	Divider, Bin
13	2194764W	Extension, Top
14	2182132	Door Closer, Upper Cam
15	489420	Screw
16	2195950	Bracket, Door Stop
17	2165792	Butter Dish
20	489084	Screw
21	2174006	Cover, End Cap

FREEZER DOOR PARTS

For Model: 3XARG497WP01

(White)



1	2197783W	Freezer Door (Includes Item #8 And Dispenser Front Parts)
2	2194759W	Handle
3	2162412	Connector
4	489463	Screw
5	2179399	Shim, End Cap (2)
6	2156021	Trivet, Shelf (2)
7	2179578	Shelf Bin (2)
8	2159072	Door Gasket, Magnetic (Service)
9	2195926	Trim, Door Shelf
10	3400012	Screw
11	2156146	Chute, Ice
12	2182132	Door Closer, Upper Cam
13	489420	Screw
14	2195950	Bracket, Door Stop
15	2156006	Plug, Trim
17	2194766W	Extension, Bottom
18	2194764W	Extension, Top
21	489084	Screw
22	2174006	Cover, End Cap

DISPENSER FRONT PARTS

For Model: 3XARG497WP01

(White)



1	2166858	Shroud, Bracket
2	2175226	Cover, Switch
3	2175227	Switch, Guard
4		Housing, Dispenser (Not Serviced)
5	488687	Screw
7	2152717	Frame, Slides
8	2152720	Slide, Cube/Crush Switch
9	2167269	Door, Ice
10	2157650	Door Mechanism Assembly
12	1120581	Mechanism Delay
13	1126120	Grille, Overflow
14	987917	Clip, Bearing (2)
15	983697	Bearing, Lever (3)
16	983696	Spring, Lever (2)
17	2147165	Shield, Wiring
18	488500	Screw
19	488362	Screw
20	489476	Nut
21	486734	Lock Washer
22	2157744	Water Fitting Assembly (Includes Water Tube)
24	2177144	Lever, Ice Dispenser
25	1124730	Guide, Ice
26	488892	Screw
27	2152726	Slide, Light Switch
29	2166862	Lamp Holder
30	488361	Screw
31	2162361	Switch (4)
32	2147164	Insulator, Control Bracket
33	2147163	Bracket, Control
34	989331	Bulb, Light
38	2177149	Lever, Water Dispenser
39	2175023	Plaque, Front Cover
40	2175130	Front Cover, Housing (Includes Item 39)
41	2147172	Heat Shield, Frame
45	489000	Screw
48	625834	Spacer

UNIT PARTS

For Model: 3XARG497WP01

(White)















1	486692	Speed Nut
2	1108179	Fan, Blade
3	2198175	Condenser Assembly
4	489464	Screw
6	489099	Screw
7	2149293	Heat Shield And Drain Pan
8	940073	Clip
9	2158826	Dampner
12	2162358	Cover
13	2169412	Overload
14	2161324	Clip, Defrost Heater
15	2154755	Relay
17	2154718	Capacitor
19	509812	Screw Grommet
20	2182057	Unit Cover, Bottom
21	489396	Clip
22	2164518	Evaporator
24	2198746	Motor, Fan
25	2154114	Tray, Evaporator
26	2195108	Unit Harness
27	2164409	Drier
28	2183423	Compressor (Includes Items 12, 13, 15, 17, 27 & 38) (Also Order)
	876765	Tube Kit
30	2160500	Unit Mounting Frame
32	2181929	Bracket, Fan Motor
33	2175046	Heater, Defrost
34	2161330	Clip
35	2176066	Bi-Metal, Defrost
37	489373	Screw
38	2172890	Wire Assembly
39	1100826	Grommet (4)
40	489340	Screw
41	2149128	Air Baffle
42	2155547	Clip, Heat
48	2149717	Unit Mounting Rail
49	488624	Screw
50	1105612	Guard, Fan
51	2161302	Sleeve
52	2172840	Wire Tie
53	489427	Screw
54	850145	Wire Connector
55	489478	Screw
59	2155658	Clip, Wire & Tube
61	488687	Screw
62	934011	Clip, Tube (3)
63	2150347	Union
64	983659	Tube, Spring

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE 5.5 oz. (R-134A)

ICEMAKER PARTS

For Model: 3XARG497WP01

(White)



1	489084	Screw
2	2182015	Fitting, Water Tube
3	488878	Clamp, Tube
4	2181939	Insert, Tube
5	628379	Clip, Fuse
6	489115	Clip
7	2181943	Tube, Water
8	1106508	Seal, Gasket
9	489478	Screw
10	2175056	Valve, Solenoid
11	627018	Nut, Compression
12	1129722	Washer (2)
14	628337	Washer
15	627861	Tube, Inlet Valve
16	510716	Clamp, Tube
17	537588	Nut, Valve
18	2174183	Cover
19	488649	Screw
20	628282	Mold & Heater Assembly (Also Order)
	542638	Silicone Grease
21	836074	Dampner
22	628356	Cup-Water Fill
23	627843	Ejector
24	2182124	Ice Striper
25	2195914	Support
26	627796	Retainer, Thermostat
27	627985	Thermostat (Also Order)
	542369	Cement Alumilastic
28	489322	Screw
29	628377	Motor Module
30	489276	Screw
31	2171593	Shut Off Arm
32	628281	Harness, Wiring
33	628320	Bracket
34	1129723	European Water Connection Tube
35	628377	Module Assembly (Includes Items 29, 37 & 38)
37	628303	Motor
38	489136	Screw
39	2182414	Heat Shield
40	1129179	Nut, Compression
42	488886	Screw

CONTROL PARTS

For Model: 3XARG497WP01

(White)



1	2161459	Control Box
2	2182150	Tube Barrier, Thermostat
3	489214	Screw (3)
4	2149705	Light Switch
5	2182770	Thermostat (FC)
6	2162057	Defrost Timer
7	489398	Screw (2)
8	2169193	Shroud, Light
9	2161460	Thermostat (R.C.)
10	2172940	Window
11	2172906	Grommet, Light Bar
12	2161466	Slide, Thermostat
13	489084	Screw (2)
14	2179920	Light Bar (RC)
15	486632	Washer
16	489290	Screw (2)
17	2162085	Light Socket
18	2172931	Heat Shield
19	851682	Light Bulb
20	2183733	Control Box Harness
22	1115375	Clip, Wiring
23	2196003	Tube Barrier, Thermostat
24	2166844	Hole Plug
25	2175179	Escutcheon, Control Box
26	2179921	Light Bar (FC)
27	2172941	Window

Parts Not Illustrated and Optional Parts (Not Included)

Customer Touch-Up Material

350942	*Primer, White (13 Oz. Spray Can)
350939	*Enamel, Black (13 Oz. Spray Can)
350930	*Enamel, White (13 Oz. Spray Can)
350956	*Enamel, Almond (13 Oz. Spray Can)
72017	Brush Touch-Up Kit (White)
72107	Brush Touch-Up Kit (Almond)
72032	Brush Touch-up kit (Black)

*CAUTION: The spray paint is not to be used where the paint may make contact with the door gaskets.

Miscellaneous

212643	Sealer, Gum (4 Feet)
479502	Tape, Vinyl (3/4 x 108")
876370	Kit, Insulation (2 Pcs. x 3" x 24" X 48")
876305	Kit, Insulation (14 Pcs. x 3" x 24" x 48")
978941	Insulation, Fiberglass (63-1/2" x 35-1/2" X 2-5/8)
876029	Kit, Foam Slab (30" x 32-1/2" x 1-1/2")
505587	Sealer, Mastic (1 Qt.)
503695	Cork, Sealer (1/4 Pound)
511873	Touch-Up, White Porcelain (2 Oz.)
542638	Grease, Silicone (1/2 Oz.)
542639	Cement, Alumilastic (1-1/4 Oz.)
606755	Bag, Insulation (36-5/8" x 46")
799833	Kit, Evaporator Repair (Aluminum Epoxy)
833938	Kit, Terminal Connector
2152735	Ice Crusher Mech. Assembly

	2182097	Ice Container Assembly

Refinishing Material

	799340	Enamel, Black (1 Qt. Uncut)
	799344	Enamel, White (1 Qt. Uncut)
	978883	Enamel, Almond (1 Qt. Uncut)

LITERATURE PARTS

	LIT2183768	Use & Care Guide
	LIT2189520	Energy Label
	LIT2176799	Wiring Diagram
	LIT628371	Modular Icemaker Service Sheet

TORX SCREW WRENCH

	1117510	Torx Key